

# HP Photosmart A717 Compact Photo Printer



Take this printer with you for prints without a PC, and store up to 4000 photos. View and edit via the 6.35 cm display – or connect to your TV – and print from passport size to 13 x 18 cm. Remove red-eye and choose a range of creative effects.

**The HP Photosmart A717 Compact Photo Printer is designed for people who want the convenience of being able to store as many as 4000 photos, and to view, edit and print instant-drying, full size 13 x 18 cm photos – without a PC.**

**Save up to 4000 photos on your printer for easy viewing, sharing and printing.**

Store and organise up to 4000 photos on the 4 GB internal memory and view/select via the clear 6.35 cm display. Edit and print almost anywhere – even connect to a TV for a slideshow or video clips and select and print using a remote. Easy to carry with built-in handle and fold-up tray. Save and print photos directly from PictBridge-enabled cameras, from optional memory cards <sup>2</sup>, from your iPod or via selected camera phones with an optional Bluetooth wireless adapter <sup>3</sup>.

**Get brilliant prints from passport size to 13 x 18 cm – with HP Photo Fix button.**

Print a variety of sizes including passport, 10 x 15 cm and 13 x 18 cm – even video frames and greetings cards – all without a PC. Use HP Real Life technologies to automatically remove red-eye, sharpen photos and improve colour, all with the unique, one-touch HP Photo Fix button. Print beautiful photos in rich true-to-life colour, or choose an artistic or vintage look in black and white or sepia tones. Enhance photos directly on your printer – choose from over 140 creative effects.

**Print instant-drying, water-resistant photos <sup>1</sup>.**

Get instant-drying, water-resistant photos when you print using HP Viverna Inks and HP Advanced Photo Paper – pass them around straight from the printer and let friends enjoy them without risk of smudging or smearing. Get great results fast too – print a beautiful 10 x 15 cm photo in as fast as 39 seconds. Get fully mobile and print wherever you go – in the car, outdoors, on holiday – with the optional rechargeable battery (not included, please purchase separately).

<sup>1</sup> Only when printed using HP Advanced Photo Paper.

<sup>2</sup> Supports CompactFlash, Memory Stick, Secure Digital/MultiMediaCard, xD-Picture Card, Memory Stick Duo (with adapter) and Mini SD (with adapter). Memory cards not included, please purchase separately.

<sup>3</sup> Bluetooth wireless adapter not included.

Supports camera phones with Bluetooth wireless technology.

Visit <http://www.hp.com/support/bluetooth> for a list of compatible devices.

## Technical specifications

|  |  |                   |                    |                   |                   |
|--|--|-------------------|--------------------|-------------------|-------------------|
| <b>Print technology</b>                | HP Thermal Inkjet  |                   |                    |                   |                   |
| <b>Print Head Nozzles</b>              | 600 colour ink nozzles   |                   |                    |                   |                   |
| <b>Print speed</b>                     | <b>Document type</b>   | <b>Draft</b>      | <b>Fast normal</b> | <b>Normal</b>     | <b>Best</b>       |
|  | <b>10 x 15 cm colour photo (photo paper)</b>   | As fast as 39 ppm | As fast as 39 ppm  | As fast as 53 ppm | As fast as 98 sec |
|  | Dependent upon type, print mode and approximate figures. Exact speed will vary depending on the system configuration, software program and photo density.  |                   |                    |                   |                   |
| <b>Print quality</b>                   | Colour: Up to 4800 x 1200 optimised dpi when printing from a computer and 1200 input dpi   |                   |                    |                   |                   |
| <b>Operating systems compatibility</b> | Windows® 98 SE, 2000, Me, XP Home, XP Professional, XP Professional x64 Edition; Mac OS X v10.3.9 and higher   |                   |                    |                   |                   |
| <b>Minimum system requirements</b>     | Windows®: Pentium® II (or equivalent) or higher; 64 MB RAM; 200 MB available hard disk space; SVGA 800 x 600 monitor with 16-bit colour; 4x CD-ROM drive; USB port and USB cable (not included); Windows® 98 SE, 2000, Me, XP Home, XP Professional, XP Professional x64 Edition<br>Macintosh: Mac OS X v10.3.9 and higher; G3 processor or compatible; 128 MB RAM; 150 MB available hard disk space for software installation; SVGA 800 x 600 monitor with 16-bit colour; HP Memories Disc Creator Software, requires CD writer and 700 MB of hard disk space |                   |                    |                   |                   |
| <b>Memory</b>                          | 96 MB (printer memory) / 4 GB internal hard disk for archiving and storing of images   |                   |                    |                   |                   |
| <b>Recommended media weight</b>        | HP photo papers up to 280 g/m²   |                   |                    |                   |                   |
| <b>Recommended media</b>               | HP Advanced Photo Paper: 10 x 15 cm and 13 x 18 cm   |                   |                    |                   |                   |
| <b>Media sizes</b>                     | Standard: 10 x 15 cm, 10 x 30 cm, 13 x 18 cm, Custom: 10 x 15 cm, 10 x 30 cm, 13 x 18 cm   |                   |                    |                   |                   |
| <b>Media handling/input</b>            | Sheets: Up to 20, Cards: Up to 20  |                   |                    |                   |                   |
| <b>Paper input tray</b>                | Standard: 1, optional: 1   |                   |                    |                   |                   |
| <b>Media handling/output</b>           | Up to 20   |                   |                    |                   |                   |
| <b>Duplex printing</b>                 | None   |                   |                    |                   |                   |
| <b>Power requirements</b>              | Input voltage: 120 VAC, 60 Hz, 0.6 amp; 110 to 240 VAC, 50/60 Hz, 0.8 amp, External power supply module, optional internal Lithium-Ion battery (not included, sold separately)   |                   |                    |                   |                   |
| <b>Power consumption</b>               | 32 watts maximum   |                   |                    |                   |                   |
| <b>Interface and connectivity</b>      | USB - compatible with USB 2.0 specification, PictBridge, memory card slots, TV output, optional: HP bt450 Bluetooth Wireless Printer and PC Adapter  |                   |                    |                   |                   |
| <b>Control panel</b>                   | 9 front-panel buttons (On, Save, Photo Fix & Rotate, Delete, Menu, Print, Cancel, Select, Zoom)  |                   |                    |                   |                   |
| <b>Software included</b>               | HP Photosmart Essential and HP Photosmart Premier software   |                   |                    |                   |                   |
| <b>Dimensions (w x d x h)</b>          | Out of package: 252 x 231 x 174 mm, with trays up: 252 x 118 x 126 mm, Maximum: 252 x 231 x 174 mm, packaged: 300 x 165 x 211 mm   |                   |                    |                   |                   |
| <b>Weight</b>                          | Out of package: 1.57 kg, packaged: 2.5 kg  |                   |                    |                   |                   |
| <b>Operating environment</b>           | Environmental ranges: operating temperature: 0 to 45° C; Recommended operating temperature: 15 to 35° C; operating humidity: 5 to 95% RH; Recommended operating humidity: 20 to 80% RH; Storage temperature: 30 to 65° C; Storage humidity: 5 to 95% RH; noise level per iso 9296: sound power: lward 5.5 B(A)   |                   |                    |                   |                   |
| <b>Energy star</b>                     | No   |                   |                    |                   |                   |
| <b>Supplies life</b>                   | For information on cartridge page and photo yields, see <a href="http://www.hp.com/go/pageyield">http://www.hp.com/go/pageyield</a>  |                   |                    |                   |                   |
| <b>Warranty</b>                        | Standard one-year limited hardware warranty. Warranty and support options vary by product, country and local legal requirements.   |                   |                    |                   |                   |

## Ordering information

|               |  |
|---------------|--|
| <b>Q7102A</b> | HP Photosmart A717 Compact Photo Printer, HP 110 Tri-colour Inkjet Print Cartridge (5 ml) CB304AE, 10 x 15 cm photo media sampler, HP Photosmart Essential Software, setup guide, user's guide, power supply |
|---------------|--|

| Accessories   |   |
|---------------|---|
| <b>C6518A</b> | HP USB Cable, 2m                            |
| <b>Q6410A</b> | HP Carrying Case for compact photo printers |
| <b>Q6398A</b> | HP bt450 Bluetooth Wireless Printer Adapter |
| <b>Q5599B</b> | HP Battery for compact photo printers       |

| Supplies       |  |
|----------------|--|
| <b>Q8700AE</b> | HP 110 Series Photo Value Pack with Vivera Inks-10 x 15 cm/120 sht |
| <b>CB304AE</b> | HP 110 Tri-colour Inkjet Print Cartridge with Vivera Inks          |

| Media         |   |
|---------------|---|
| <b>Q8695A</b> | HP Advanced Glossy Photo Paper 250 g/m²-13 x 18 cm borderless/50 sht  |
| <b>Q8692A</b> | HP Advanced Glossy Photo Paper 250 g/m²-10 x 15 cm borderless/100 sht |
| <b>Q8691A</b> | HP Advanced Glossy Photo Paper 250 g/m²-10 x 15 cm borderless/25 sht  |

For a complete list of supplies, media and accessories, please refer to the HP website at <http://www.hp.com>

<http://www.hp.com/go/photosmart> <http://www.hp.com>

